

## Pump Nitrogen Unit N2



Skid N2 unit. Placed on the trailer

It can be used both offshore and land

Tank and unit both skids